


HOME DECORATORS COLLECTION

HDC# 10492 MFG# TW-18696BK / TW-18696CC
ESSEX ROUND COFFEE TABLE 36" DIAMETER

ASSEMBLY INSTRUCTIONS

- Note: 1. Before assembly, please be sure to work on a soft, flat surface to avoid any damage to the finish.
2. It needs at least 2 persons to finish the assembly of this product.

Made In China







BEFORE ASSEMBLY

IMPORTANT NOTE: READ CAREFULLY BEFORE ASSEMBLY TO PREVENT DAMAGE TO PARTS. FOLLOWING INSTRUCTIONS LISTED BELOW IN THE PROPER SEQUENCE AS NUMBERED TO ASSURE FAST, EASY AND CORRECT ASSEMBLY.

THANK YOU FOR PURCHASING THIS QUALITY PRODUCT. BE SURE TO CHECK ALL PACKING MATERIAL CAREFULLY FOR SMALL PARTS, WHICH MAY HAVE CAME LOOSE INSIDE THE CARTON DURING SHIPMENT. COUNT ALL PARTS AND MATERIAL HARDWARE, COMPARE WITH PARTS LIST TO BE SURE ALL PARTS ARE PRESENT. IF ANY PARTS ARE MISSING OR DAMAGED, PHONE, FAX OR MAIL TO OUR CUSTOMER SERVICE DEPARTMENT. FOR EFFICIENT AND SPEEDY SERVICE, PLEASE INDICATE THE MODEL NUMBER AND CODE LETTER OF PART NEEDED.


PARTS LIST

<div>TOP FRAME 1 PC</div> <div></div> <div>A</div>	<div>BOTTOM PANEL 1 PC</div> <div></div> <div>B</div>	<div>LEG 4 PCS</div> <div></div> <div>C</div>
<div>LEG 4 PCS</div> <div></div> <div>D</div>		

NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

STEP 1: ASSEMBLE TOP FRAME (A) AND LEG (C)

- ROTATE LEG (C) ONTO TOP FRAME (A) TIGHTLY AS SHOWN.



STEP 2: ASSEMBLE BOTTOM PANEL (B) AND LEG (D)

- USE LEG (D) TO ASSEMBLE BOTTOM PANEL (B) AND LEG (C) TOGETHER AS SHOWN.

